

LB7 ECM Connector wiring installation

#1 – Remove TCM cover	#2 – Lift out TCM	#3 – Disconnect TCM
		
#4 – Remove ECM cover	#5 – Unbolt blue plug	#6 – Remove blue cover
		
#7 – Pins now exposed	#8 – Insert new pin/wire	#9 – Re-assemble
		